



SUPPLIES, MATERIALS & EQUIPMENT NEEDED FOR THE X.J.S.TM INSTALLATION

SUPPLIES:

1. Blast Sand
2. DOW or USG – 15 lb. Density Rigid Insulation Board in 1" Thickness (*extruded only*)
3. DOW or Amoco 1/4" Foam Protection Board
4. Duct Tape
5. Silspec® 900 PNS and Aggregate
6. Backer Rod (*soft type*)
7. Small amount of 5/8" or 7/8" Tundra Foam
8. Dow Corning 902 RCS and Dow Corning 1205 Primer
9. Rags
10. Waterless Hand Cleaner
11. Gloves, Goggles
12. Water for Clean up (*10-15 gallons*)
13. Ameron 160A Zinc Rich Primer (*if required*)
14. Clean, empty, 5-gallon bucket
15. Rubber Kitchen Spatula
16. 1" and 3" Paint Brushes

HAND TOOLS:

1. Break-away knives
2. 4' or 6' straight edge
3. 24" straight 2" x 4"
4. 14" x 4" Cement Finishing Trowel (*steel*)
5. 5" x 1/2" Margin Trowel
6. Tape Measure

EQUIPMENT:

1. Concrete Saw
2. Paving Breaker with Wide Chisel
3. Air Compressor
4. Sand Blast Equipment
5. Generator
6. Mortar Mixer 3-6 Cubic Feet
7. Chain or Quickie Saw
8. Pump or Gun for 902 RCS
9. Electric Hand Drill (*min. 1/2 HP*) and Small Mixer Paddle
10. Hand Grinder